

Bentice

T.O. 21M-HGM25A-1-1

WWW.CHROMEHOOVES.NET

TECHNICAL MANUAL

OPERATION AND ORGANIZATIONAL
MAINTENANCE

USAF MODEL

HGM-25A

MISSILE WEAPON SYSTEM
OPERATION

AF 04(645)-56

AF 04(694)-395

**CHANGE
NOTICE**

LATEST CHANGED PAGES SUPERSEDE
THE SAME PAGES OF PREVIOUS DATE

Insert changed pages into basic publication.
Destroy superseded pages

PUBLISHED UNDER AUTHORITY OF THE SECRETARY OF THE AIR FORCE

AIR FORCE—A. B. Hirschfeld Press, Denver, Colo., 13 April 64—2300 (Martin Marietta)

TOCN 1-1 (DEN-12)

1 AUGUST 1963

CHANGED 19 MARCH 1964

WWW.CHROMEHOOVES.NET

Reproduction for nonmilitary use of the information or illustrations contained in this publication is not permitted without specific approval of the issuing service. The policy for use of Classified Publications is established for the Air Force in AFR 205-1.

INSERT LATEST CHANGED PAGES, DESTROY SUPERSEDED PAGES.

LIST OF EFFECTIVE PAGES

NOTE: The portion of the text affected by the changes is indicated by a vertical line in the outer margin of the page.

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 581 CONSISTING OF THE FOLLOWING:

Page No.	Issue	Page No.	Issue
*Title	19 Mar 64	3-17.13 Mar 64
*A thru C	19 Mar 64	3-18 thru 3-21.	Original
i thru iiiOriginal	3-22.	3 Jan 64
iv	3 Jan 64	3-23 thru 3-30.	Original
v.	18 Dec 63	3-31.17 Jan 64
viOriginal	3-31A Added17 Jan 64
vii.	18 Dec 63	3-32.17 Jan 64
viii thru ixOriginal	3-32A thru 3-32E Added. .17 Jan 64	
*x thru xA.	19 Mar 64	3-33.	Original
xi thru xii.	18 Dec 63	3-34.18 Dec 63
xiii	31 Jan 64	3-35.17 Jan 64
xiv.	18 Dec 63	3-36.	Original
xv thru xxxiOriginal	3-37.17 Jan 64
xxxii.	18 Dec 63	3-38.	Original
xxxiii	20 Feb 64	3-39.17 Jan 64
1-1.5 Nov 63	3-40 thru 3-41.	Original
1-1A Added5 Nov 63	3-42.13 Mar 64
1-2 thru 1-16.Original	3-43 Deleted.13 Mar 64
1-17	18 Dec 63	3-44 thru 3-51.	Original
1-18Original	3-52.13 Mar 64
1-19	18 Dec 63	3-53 Deleted.13 Mar 64
1-19A Added.	18 Dec 63	3-54 thru 3-58.13 Mar 64
1-20	18 Dec 63	3-58A Deleted13 Mar 64
1-21 thru 1-33Original	3-59 thru 3-63.13 Mar 64
1-34 thru 1-35	16 Jan 64	3-64 thru 3-65.	Original
1-36 thru 1-39Original	3-66.18 Dec 63
1-40	16 Jan 64	3-67.20 Feb 64
1-41Original	3-67A Added20 Feb 64
1-42	18 Dec 63	3-68.17 Jan 64
1-43 thru 1-50Original	3-69 thru 3-71.	Original
1-51	18 Dec 63	*3-72 thru 3-77.19 Mar 64
1-52 thru 1-57Original	*3-77A Deleted19 Mar 64
1-58	3 Jan 64	*3-78 thru 3-82.19 Mar 64
1-59	17 Jan 64	*3-82A Deleted19 Mar 64
1-60	18 Dec 63	*3-83.19 Mar 64
1-61 thru 1-143.Original	*3-83A Deleted19 Mar 64
2-1 thru 2-2Original	*3-84 thru 3-86.19 Mar 64
3-1 thru 3-16.Original		

*The asterisk indicates pages changed, added, or deleted by the current change.

ADDITIONAL COPIES OF THIS PUBLICATION MAY BE OBTAINED AS FOLLOWS:
 USAF ACTIVITIES.—In accordance with T.O. 00-5-2.

USAF

Page No.	Issue	Page No.	Issue
3-86A thru		4-18 thru 4-24.	Original
3-86G Added	13 Mar 64	4-25.	17 Jan 64
3-87 thru 3-89.	Original	4-26 thru 4-29.	Original
3-90.	17 Jan 64	4-30.	31 Jan 64
3-91 thru 3-101.	Original	4-31.	18 Dec 63
3-102	17 Jan 64	4-32 thru 4-34 Deleted.	18 Dec 63
3-103 thru 3-128.	Original	4-35 thru 4-36.	Original
3-129	7 Oct 63	4-37.	18 Dec 63
3-130	20 Feb 64	4-38 thru 4-39 Deleted.	18 Dec 63
3-130A.	13 Mar 64	4-40 thru 4-45.	Original
3-131 thru 3-132.	20 Feb 64	4-46.	17 Jan 64
3-133	18 Dec 63	4-47.	18 Nov 63
3-134 thru 3-135.	20 Feb 64	4-48.	17 Jan 64
3-136 thru 3-138.	17 Jan 64	4-49.	13 Mar 64
3-138A Added.	17 Jan 64	4-50.	Original
3-139	17 Jan 64	4-51 thru 4-52.	18 Nov 63
3-140	Original	4-53 thru 4-58.	Original
3-141	31 Jan 64	4-59.	3 Jan 64
3-142 thru 3-143.	13 Mar 64	4-60.	18 Dec 63
3-144 thru 3-145.	Original	4-61.	5 Nov 63
3-146	3 Jan 64	4-62 thru 4-63.	Original
3-147	17 Jan 64	5-1 thru 5-2.	3 Jan 64
3-147A Added.	3 Jan 64	5-3 thru 5-4.	18 Dec 63
3-148 thru 3-151.	Original	5-5 Deleted	18 Dec 63
3-152 thru 3-154.	18 Dec 63	5-6	18 Dec 63
3-154A Added.	18 Dec 63	*5-7	19 Mar 64
3-155 thru 3-157.	Original	5-8 thru 5-10	18 Dec 63
3-158 thru 3-164.	18 Dec 63	5-11 Deleted.	18 Dec 63
3-164A thru		5-12.	17 Jan 64
3-164B Added.	18 Dec 63	5-13.	18 Dec 63
3-165 thru 3-168.	Original	5-14 thru 5-15.	Original
3-169	18 Dec 63	5-16 thru 5-20.	17 Jan 64
3-170	Original	5-20A Added	17 Jan 64
3-171	18 Dec 63	5-21 thru 5-22.	Original
3-171A Added.	18 Dec 63	5-22A Added	18 Dec 63
3-172 thru 3-176.	Original	5-23 thru 5-25.	Original
3-177	18 Dec 63	5-26.	31 Jan 64
3-178 thru 3-185.	Original	5-27.	Original
3-186	18 Dec 63	5-28.	31 Jan 64
3-187 thru 3-232.	Original	5-29 thru 5-30.	Original
4-1	3 Jan 64	5-31 thru 5-33.	31 Jan 64
4-1A Added.	3 Jan 64	5-34 thru 5-35.	Original
4-2 thru 4-3.	Original	5-36.	31 Jan 64
4-4 thru 4-5.	18 Dec 63	5-37 thru 5-38.	Original
4-6 thru 4-11	Original	5-39.	13 Mar 64
4-12 thru 4-13.	18 Dec 63	5-40 thru 5-43.	Original
4-13A Added	18 Dec 63	5-44.	17 Jan 64
4-14 thru 4-17.	17 Jan 64	5-45 thru 5-46.	Original

*The asterisk indicates pages changed, added, or deleted by the current change.

Page No.	Issue
5-47 thru 5-48.31 Jan 64
5-49.17 Jan 64
5-50.	5 Nov 63
5-51 thru 5-52.17 Jan 64
5-52A Added17 Jan 64
5-53 thru 5-54.	5 Nov 63
6-1 thru 6-7.	Original
7-1 thru 7-3.	Original
GLOSSARY-1 thru GLOSSARY-9.	Original
INDEX-1 thru INDEX-2	Original
*INDEX-3 thru INDEX-3A19 Mar 64
INDEX-417 Jan 64
INDEX-5 thru INDEX-10.	Original

WWW.CHROMEHOOVES.NET

WWW.CHROMEHOOVES.NET

WWW.CHROMEHOOVES.NET

*The asterisk indicates pages changed, added, or deleted by the current change.

TABLE OF CONTENTS

I GENERAL DESCRIPTION

1-1	Introduction	1-1
1-3	SM68 Missile	1-1
1-4	Leading Particulars	1-1
1-6	Countdowns	1-1
1-14	Post Launch and Shutdown Operations	1-4
1-16	Propellants	1-4
1-18	External Cable Conduits	1-4
1-20	Access Panels	1-4
1-22	Ordnance	1-4
1-28	Vernier Nozzles	1-6
1-30	Launch Complex	1-6
1-31	Leading Particulars	1-6
1-34	Missile Silo	1-6
1-49	Equipment Terminal	1-17
1-60	Propellant Terminal	1-27
1-64	Control Center	1-27
1-79	Power House	1-42
1-82	Antenna Terminal	1-42
1-87	Fuel Terminal	1-48
1-98	Portal	1-51
1-100	Tunnels	1-51
1-106	Local Control Stations	1-53
1-111	Pump House and Spray Ponds (VAFB)	1-53
1-114	Facility Systems	1-53
1-116	Facility Air Conditioning, Heating, and Ventilating System	1-57

Section	Page
1-123 Portal and Antenna Silo Environmental Seal Heating Systems.	1-58
1-125 Power Generation System	1-58
1-127 Power Distribution System	1-58
1-129 Water Supply, Distribution, and Waste Systems	1-58
1-136 Sanitary Sewage System.	1-59
1-138 Non-sanitary Waste System	1-59
1-140 Sensing, Warning, and Blast Protection Systems.	1-59
1-142 Utility Compressed Air System	1-59
1-144 Plant Compressed Air System	1-59
1-148 Portal Hydraulic System	1-62
1-151 Instrument and TV Camera Mount Elevators.	1-62
1-153 Antenna Silo Personnel Elevators (Operational bases).	1-62
1-155 Subsystems.	1-62
1-158 Guidance System	1-62
1-192 Flight Control System	1-86
1-212 Electrical System	1-96
1-236 Engine System	1-98
1-282 Propellant System	1-107
1-302 Missile Launcher System	1-113
1-334 Re-Entry Vehicle System	1-117
1-346 Launch Sequencer.	1-118
1-348 Control Center Circuits	1-118
1-363 Time Display Board.	1-121
1-369 Hydraulic System.	1-121
1-397 Missile Air Conditioning System	1-127
1-405 Communication System.	1-129
1-407 Instrumentation and Range Safety System Facilities (VAFB)	1-129
1-410 Mobile Telemeter Station.	1-131

Section	Page
1-412 Command Destruct Facilities	1-131
1-414 Radar Tracking Facilities	1-131
1-416 AME-Cotar Fields.	1-131
1-418 Radar Surveillance System AN/TPS-39(v).	1-131
1-419 Purpose	1-131
1-421 Description	1-133
1-426 Maintenance Plan.	1-133
1-428 Organizational Level and Field Level Maintenance.	1-133
1-437 Depot Maintenance	1-142
1-441 Scheduled and Unscheduled Maintenance	1-143
1-445 Commodity Servicing	1-143
1-446 Diesel Fuel	1-143
1-448 Liquid Oxygen, Liquid Nitrogen, Gaseous Nitrogen, Helium and Rocket Fuel (RP-1).	1-143
 II RECEIPT THROUGH LAUNCH	
2-1 Scope	2-1
2-3 Missile and Re-Entry Vehicle Installation and Checkout.	2-1
2-5 Alert Status Monitoring	2-1
2-7 System Exercises.	2-1
2-9 Tactical Launch (EWO)	2-1
2-11 Post Launch	2-1
 III NORMAL OPERATING PROCEDURES	
3-1 Scope	3-1
3-3 Crew Administrative Procedures.	3-1
3-5 Crew Inspection	3-1
3-7 Pre-Departure Crew Briefing	3-1
3-9 Complex Entry Procedures (Operational bases).	3-1
3-11 Crew Shift Change Briefing.	3-1

Section	Page
3-13 Crew Operations Briefing,.....	3-4
3-15 Individual Changeover.....	3-4
3-17 Activity Coordination Briefing.....	3-4
3-33 Special Activities Briefing.....	3-15
3-35 Personnel Control.....	3-16
3-39 Contingency Procedures.....	3-16
3-44 Seven High/Redskin Notification System.....	3-20
3-48 Serious Illness or Injury.....	3-22
3-50 Severe Weather Report Procedure.....	3-22
3-52 Deleted	
3-54 Exit Procedures (Operational Bases).....	3-22
3-56 Radar Surveillance System (Anti-intrusion).....	3-22
3-71 Security Procedures.....	3-27
3-83 Alert Status Monitoring.....	3-30
3-85 Weather Information.....	3-30
3-87 Index of Refraction.....	3-30
3-94 Launch Site Targeting Procedure.....	3-89
3-96 Launch and Exercise Countdowns.....	3-89
3-98 Alert Procedures.....	3-89
3-109 Fast Reaction Message.....	3-123
3-111 Launch, Exercise, and Guidance Countdown Procedures.....	3-123
3-113 Power House Countdown Procedure.....	3-124
3-115 Launch Countdown System Functions.....	3-124
 IV EMERGENCY PROCEDURES	
4-1 General.....	4-1
4-5 Boil-off Procedure.....	4-1
4-7 OSBV Lox Dump.....	4-1

Section	Page
4-10 Recycle of Electrical System and PLPS.....	4-2
4-12 Verification of Lox Tanks Empty.....	4-2
4-14 Hazard Procedures.....	4-2
4-16 Radar Surveillance System (Anti-Intrusion).....	4-2
4-17 Alarm Indication.....	4-2
4-19 Primary Power Failure.....	4-3
4-21 Jamming and Anti-Jamming.....	4-3
V COMBAT CREW MALFUNCTION ISOLATION	
5-1 Scope.....	5-1
5-3 Malfunction Isolation.....	5-1
5-5 Malfunction Isolation of Propellant Loading and Pressurization System.....	5-1
5-7 Malfunction Isolation of Electrical System.....	5-1
5-9 Malfunction Isolation of Flight Control System.....	5-1
5-11 Malfunction Isolation of RVS and GMTS.....	5-1
5-12A Malfunction Isolation for Launcher.....	5-2
5-13 Malfunction Isolation for Guidance.....	5-2
5-15 Malfunction of Power House.....	5-2
VI OPERATING LIMITATIONS	
6-1 Scope.....	6-1
6-3 Weather Limitations.....	6-1
6-6 Power House.....	6-1
6-7 One Generator Operation.....	6-1
6-9 Diesel Fuel Oil Supply.....	6-2
6-11 Ice Banks.....	6-2
6-13 Countdown Limitations.....	6-2
6-14 First Hold Period.....	6-2
6-17 Second Hold Period.....	6-2

Section		Page
6-20	Launch Platform Raising and Lowering.	6-4
6-28	Launcher Platform Operating Weight Limits	6-5
6-32	Target Selection.	6-7
6-34	GGs Malfunction or Not-Ready.	6-7
6-36	Handover or Shutdown.	6-7
6-38	Radar Surveillance System	6-7
 VII CREW DUTIES		
7-1	Scope	7-1
7-3	General	7-1
7-5	Missile Combat Crew Commander (MCCC).	7-1
7-7	Missile Launch Officer (MLO).	7-1
7-9	Guidance Electronics Officer (GEO).	7-2
7-11	Ballistic Missile Analyst Technician (BMAT)	7-2
7-13	Missile Maintenance Technician (MMT).	7-3
7-15	Electrical Power Production Technicians (EPPT).	7-3
GLOSSARY		GLOSSARY-1
ALPHABETICAL INDEX		INDEX-1

LIST OF ILLUSTRATIONS

Number	Title	Page
1-1	Missile Configuration	1-2
1-2	Table of Leading Particulars.	1-3
1-3	Access Panels	1-5
1-4	Operational Base Launch Complex (Sheet 1 of 3).	1-7
1-5	VAFB Launch Complex (Sheet 1 of 2).	1-10
1-6	Missile Silo.	1-12
1-7	Silo Doors.	1-14

Number	Title	Page
1-8	Crib Structure.....	1-15
1-9	Launcher Platform.....	1-16
1-10	Umbilical Tower.....	1-18
1-11	Launcher Platform Drive System (Operational Bases).....	1-19
1-11A	Launcher Platform Drive System (VAFB).....	1-19A
1-12	Umbilical Lines and Support Mechanism.....	1-20
1-13	Equipment Terminal, Level I.....	1-21
1-14	Typical Power Pack Room and Electrical Room.....	1-23
1-15	Equipment Terminal, Level II.....	1-24
1-16	Equipment Terminal, Level III.....	1-25
1-17	Equipment Terminal, Level IV.....	1-26
1-18	Propellant Terminal Lower Level.....	1-28
1-19	Propellant Terminal Upper Level.....	1-29
1-20	Control Center (VAFB).....	1-30
1-21	Control Center (Operational Bases).....	1-31
1-22	Control Center Operations Room Equipment Location (Sheet 1 of 2).....	1-32
1-23	Launch Control Console (Operational Bases).....	1-34
1-24	Launch Control Console (VAFB).....	1-35
1-25	Missile Guidance Console.....	1-38
1-26	Launch Complex Facilities Console (Operational Bases).....	1-40
1-27	Launch Complex Facilities Console (VAFB).....	1-41
1-28	Power House (VAFB).....	1-43
1-29	Power House Lower Level Typical Equipment Location (Operational Bases).....	1-44
1-30	Power House Mezzanine Typical Equipment Location (Operational Bases).....	1-45
1-31	Antenna Terminal (VAFB).....	1-46
1-32	Antenna Terminal (Operational Bases).....	1-47

Number	Title	Page
1-33	Tunnel Junction 10 (VAFB)	1-49
1-34	Tunnel Junction 12 (Operational Bases).	1-50
1-35	Tunnels and Blast Locks Location Diagram.	1-52
1-36	Ground Level Control Station.	1-54
1-37	Tunnel Entrance Control Station	1-55
1-38	Pump House and Spray Ponds (VAFB)	1-56
1-39	Table of Sensing, Warning, and Blast Protection Systems (Sheet 1 of 2).	1-60
1-40	Table of Missile Subsystems	1-63
1-41	Guidance System	1-64
1-42	Control Center Operations Room Equipment Functions (Sheet 1 of 3).	1-66
1-43	Control Center Electrical Equipment Room, Radar Equipment	1-69
1-44	Antenna Terminal Equipment Location	1-70
1-45	Antenna Terminal Equipment Functions.	1-71
1-46	Antenna Silo Equipment Location	1-72
1-47	Antenna Silo Equipment Functions (Sheet 1 of 2)	1-73
1-48	Missile Guidance Set.	1-75
1-49	Missile Guidance Set Equipment Functions.	1-77
1-50	Antenna-Mast Group OA-2903A/GRW-5 or Collimation Antenna-Mast Group (GS-58128)	1-78
1-51	Optical Camera-Telescope Target RR-101/GRW-5.	1-78
1-52	Radar Transmitting Units, Block Diagram	1-81
1-53	Missile Guidance Set AN/DRW-18, AN/DRW-19, AN/DRW-20, AN/DRW-21, or AN/DRW-22, Block Diagram.	1-83
1-54	Azimuth and Elevation Error Detection	1-84
1-55	Radar Receiving Units Block Diagram	1-85
1-56	Digital Data Printer RO-144/GSK-1, Printout Data (Sheet 1 of 6).	1-87

Number	Title	Page
1-57	Missile Axes and Movement Diagram	1-93
1-58	Stage I Engine.	1-99
1-59	Stage II Engine.	1-100
1-60	Stage I Rocket Engine Subassembly	1-102
1-61	Stage II Rocket Engine Subassembly.	1-104
1-62	Propellant System Flow Diagram.	1-108
1-63	Table of Propellant System Control Assemblies	1-111
1-64	Water Spray Equipment	1-116
1-65	Time Display Board (Operational Bases).	1-122
1-66	Stage I Hydraulic Equipment Location.	1-124
1-67	Stage II Hydraulic Equipment Location.	1-126
1-68	Missile Air Conditioning System (Operational Bases)	1-128
1-69	Conditioned Air Flow.	1-130
1-70	Typical Radar Surveillance System AN/TPS-39(V).	1-132
1-71	Class D Transmitter Set	1-134
1-72	Class D Receiver Set (Receiver Group Cover Removed)	1-135
1-73	Class A Antenna Group (Receiver or Transmitter Set)	1-136
1-74	Receiver Group.	1-137
1-75	Annunciator	1-138
1-76	Annunciator Power Supply.	1-139
1-77	Table of Radar Surveillance System AN/TPS-39(V) Capabilities.	1-140
3-1	Crew Inspection	3-2
3-2	Crew Changeover Briefing Procedures	3-3
3-3	Individual Changeover, Abbreviated Checklist Procedures (Sheet 1 of 2).	3-5
3-4	Individual Changeover, Amplified Checklist Procedures (Sheet 1 of 8).	3-7

Number	Title	Page
3-5	Broken Arrow, Bent Spear, and Dull Sword Procedures (Sheet 1 of 3).....	3-17
3-6	Seven High/Redskin Notification Procedures.....	3-21
3-7	Serious Injury or Illness Checklist Procedure (Sheet 1 of 2).....	3-23
3-8	Severe Weather Report Procedure.....	3-25
3-9	Guidance Electronics Officer Alert Status Monitoring (Standby) Procedure (Sheet 1 of 2).....	3-31
3-9A	Guidance Electronics Officer Alert Status Monitoring (Power On) Procedure (Sheet 1 of 5).....	3-32A
3-10	Ballistic Missile Analyst Technician Alert Status Monitoring Procedure (Operational Bases) (Sheet 1 of 11).....	3-33
3-11	Ballistic Missile Analyst Technician Alert Status Monitoring Procedure (VAFB) (Sheet 1 of 10).....	3-44
3-12	Missile Maintenance Technician Alert Status Monitoring Procedure (Operational Bases) (Sheet 1 of 9).....	3-54
3-13	Missile Maintenance Technician Alert Status Monitoring Procedure (VAFB) (Sheet 1 of 9).....	3-63
3-13A	Electrical Power Production Technician Alert Status Monitoring Procedure (LAFB 724TH/725TH SQDN) (Sheet 1 of 7).....	3-72
3-14	Electrical Power Production Technician Alert Status Monitoring Procedure (EAFB, BAFB, LAFB, MHAFB) (Sheet 1 of 8).....	3-79
3-14A	Facility Technician Alert Status Monitoring Procedure (Operational Bases) (Sheet 1 of 4).....	3-86A
3-14B	Facility Technician Alert Status Monitoring Procedure (VAFB) (Sheet 1 of 3).....	3-86E
3-15	Typical Weather Chart.....	3-87
3-16	Index of Refraction Calculation Procedure.....	3-88
3-17	Retargeting Flow Diagram.....	3-90
3-18	Inventory Targeting Package Procedure (Sheet 1 of 2).....	3-91
3-19	Install and Verify Guidance Program Tape and Target Tape Procedure (Sheet 1 of 6).....	3-93
3-20	Digital Guidance Simulation Procedure (Sheet 1 of 5).....	3-99
3-21	Printed Record from Digital Guidance Simulation.....	3-104

Number	Title	Page
3-22	R/V Cards and Launch Console Label Installation Procedure (Sheet 1 of 4).....	3-105
3-23	Verify Target Procedure.....	3-109
3-24	Handover Target Compatibility Procedure.....	3-110
3-25	Fast Retargeting, Install and Verify Target Tape and Verify Guidance Program Tape Procedure (Sheet 1 of 5).....	3-111
3-26	Fast Retargeting Verify Target Procedure.....	3-116

WWW.CHROMEHOOVES.NET

WWW.CHROMEHOOVES.NET

Number	Title	Page
3-27	Fast Retargeting Post Retargeting Procedure (Sheet 1 of 2).....	3-117
3-28	Fast Retargeting R/V Card and Launch Console Label Installation Procedure (Sheet 1 of 4).....	3-119
3-29	Launch Countdown Procedure (Sheet 1 of 5).....	3-125
3-30	Lox or CSE Countdown Procedure (Sheet 1 of 6).....	3-130
3-31	Guidance Countdown Procedure (Sheet 1 of 8).....	3-136
3-32	Powerhouse Countdown Procedure (Sheet 1 of 4).....	3-144
3-33	Launch Countdown System Functions (Operational Bases) (Sheet 1 of 39).....	3-148
3-34	Launch Countdown System Functions (VAFB) (Sheet 1 of 44).....	3-187
3-35	Launch Countdown System Functions Launcher Control System Lower Launcher (Sheet 1 of 2).....	3-231
4-1	Hazard Condition Chart (Sheet 1 of 2).....	4-4
4-2	Gox Hazard in Missile Silo (Sheet 1 of 3).....	4-6
4-3	Gox Hazard in Propellant Terminal (Sheet 1 of 3).....	4-9
4-4	Lox Hazard in Propellant Terminal Lox Vent (Operational Bases) (Sheet 1 of 2).....	4-12
4-5	Lox Spillage in Missile Silo (Sheet 1 of 4).....	4-14
4-6	Missile Silo Fire (Sheet 1 of 4).....	4-18
4-7	Propellant Terminal Fire (Sheet 1 of 3).....	4-22
4-8	Equipment Terminal Fire (Sheet 1 of 3).....	4-25
4-9	Hydraulic Fire, Equipment Terminal (Sheet 1 of 4).....	4-28
4-10	Deleted.	
4-11	Fire in Fuel Terminal (Sheet 1 of 3).....	4-35
4-12	Deleted.	
4-13	Missile Silo Explosion (Sheet 1 of 2).....	4-40
4-14	Lox Empty Propellant Terminal.....	4-42
4-15	Battery Power, Equipment Terminal.....	4-43
4-16	Power House Emergency (Sheet 1 of 2).....	4-44

Number	Title	Page
4-17	Loss of All AC Power (Sheet 1 of 3).....	4-46
4-18	Loss of One of Two Generators During Alert Status Monitoring (EAFB, BAFB, LAFB, MHAFFB) (Sheet 1 of 2).....	4-49
4-19	Loss of One of Two Generators During Alert Status Monitoring (LAFB 724TH/725TH SQDN).....	4-51
4-20	Loss of One of Three Generators During Countdown (LAFB 724TH/725TH SQDN).....	4-52
4-21	Two Generator Countdown (LAFB 724TH/725TH SQDN).....	4-53
4-22	Loss of Launcher Feeder AC Power.....	4-54
4-23	Loss of Power House Feeder AC Power.....	4-55
4-24	Loss of Control Center Feeder AC Power.....	4-56
4-25	Loss of Power House Intake Fan.....	4-57
4-26	Loss of Power House Exhaust Fan.....	4-58
4-27	Diesel Engine Run-Away (Sheet 1 of 2).....	4-59
4-28	Power House Fire.....	4-61
4-29	Single Generator Operation.....	4-62
4-30	Standby Diesel Engine Manual Start (LAFB 724TH/725TH SQDN).....	4-63
5-1	PLPS Red (LCFC) at TSI.....	5-3
5-2	No LOX LOADING White (LCC).....	5-4
5-3	Deleted.	
5-4	PLPS Red at LOX LOADING or T-700.....	5-6
5-5	LOX EMPTY Red (LCFC).....	5-7
5-6	PLPS Red at T-280 (Sheet 1 of 3).....	5-8
5-7	Deleted.	
5-8	GROUND POWER Red at T-870.....	5-12
5-9	GROUND POWER Red Prior to T-280.....	5-13
5-10	BATTERY POWER Red.....	5-14
5-11	GROUND POWER Red at T-280.....	5-15

Number	Title	Page
5-12	FLIGHT CONTROLS Red on LCFC (T-280) and Assembly 3A2 (Sheet 1 of 6).....	5-16
5-13	RVS Red (LCFC) T-280 or RVS Red (LCFC) T-280 and CONTROL CENTER CIRCUITS Red (Sheet 1 of 2).....	5-21
5-13A	LOWER LAUNCHER Pressed White and Launcher Remains in the Intermediate Position.....	5-22A
5-14	TSI to T-280 GUIDANCE Red.....	5-23
5-15	LAUNCHER Red, Power Pack Not Operating at T-281.....	5-24
5-16	All Guidance Indicators Not Lighted.....	5-25
5-17	CONSTANTS REGISTER 6 Inoperative.....	5-26
5-18	POWER ON Not White.....	5-27
5-19	GUID X NOT RDY Does Not Go Out (Before START GUID X Green).....	5-28
5-20	GUID X NOT RDY Does Not Go Out (After START GUID X Green).....	5-29
5-21	START CD Indicator Does Not Light.....	5-30
5-22	POWER ON Not Green (Sheet 1 of 3).....	5-31
5-23	TARGET GATED Not Green and No Gated Pulse when START GUID X is Initiated.....	5-34
5-24	MAG RDY Not White.....	5-35
5-25	MAG ON Not Green (Before LIFT OFF White).....	5-36
5-26	START GUID X Not Green.....	5-37
5-27	RAISE ANT Not White.....	5-38
5-28	ANT RAISE Not Green.....	5-39
5-29	MISSILE READY Not White.....	5-40
5-30	ACQ MISSILE Not Green.....	5-41
5-31	LIFT OFF Not White.....	5-42
5-32	GUID IN PROGRESS Not Green.....	5-43
5-33	GGF FAULT Lighted.....	5-44
5-34	ABORT Red (During GUID X Run).....	5-45
5-35	ABORT Red (During Missile Flight).....	5-46

Number	Title	Page
5-36.	MAG I Not Indicating Between 1.5 to 1.9 MA.....	5-47
5-37	Erratic MAG I Indication.....	5-48
5-38	Table of Power House Malfunction Isolation (Sheet 1 of 6).....	5-49
6-1	Maximum Allowable Hold Time, First Hold.....	6-3
6-2	Launcher Platform Operating Weight Limits.....	6-6

WWW.CHROMEHOOVES.NET

WWW.CHROMEHOOVES.NET